



Advances in Overpressure Processing Bi-2212 Insert Coils in a New, Large Overpressure Furnace

Eric Hellstrom, M. Boebinger, E. Bosque, P. Chen, A. Constantinescu, D. Davis, L. English, A. Francis, V. Griffin, S. Hahn, D. Hilton, J. Jiang, F. Kametani, Y. Kim, Jun Lu, D. Larbalestier, M. Matras, Y. Oz, W. Starch, U. Trociewitz

Applied Superconductivity Center
National High Magnetic Field Laboratory
Florida State University

Bismuth Strand and Cable Collaboration BSCCo

Funding: DOE-HEP, NSF-DMR, State of Florida



Overview

- **What is overpressure (OP) processing and why do we need it?**
- **Research-scale OP studies**
- **Large-scale OP studies**

- 1989 – first Bi-2212 round wire
- Why the renewed interest in Bi-2212?

High-field critical current densities in $\text{Bi}_2\text{Sr}_2\text{Ca}_1\text{Cu}_2\text{O}_{8+x}$ / Ag wires

K. Heine, J. Tenbrink, and M. Thöner


Vacuumschmelze GmbH, Grüner Weg 37, D-6450 Hanau 1, Germany

APL 55 (1989) 2441

(Received 29 August 1989; accepted for publication 2 October 1989)

Drawbacks of 2212




- 2212 can only be used up to 10 – 15 K
- Much higher J_c in 2212 flat tape
- 2223 and REBCO are better HTS flat tapes and can be used at 77 K



Why Bi-2212 now?

- Round wire has versatile application potentials for high-field NMR magnets and accelerator magnets *etc.*
- Multifilamentary and does not have macroscopic electromagnetic anisotropy.
- Twisted wire with significant reduction of hysteretic losses.
- A high irreversibility field - above 100 T at 4.2 K.
- Overpressure (OP) processing makes J_E of Bi-2212 very competitive.

D. Larbalestier *et al*,
Nature Materials,
Mar 13(4) (2014) 375–381






Round wire is preferred conductor geometry to build magnets


1.1 T in 31 T - first HTS wire-wound coil to go beyond 30 T

Cables for very-high-current applications



Myers, Trociewitz

Rutherford




Godeke

6-on-1





Shen





2212 powder in 2212 wire is ~60% dense - bubbles form in 2212 RW during heat treatment




X-ray tomography
Scheuerlein, Di Michiel, Scheel




Removing bubbles with overpressure (OP) processing more than doubles J_E

Direct observation of gas-filled bubbles due to powder being only 60-70% dense



OP processing squeezes wire with gas pressure to remove bubbles



Kametani, Jiang, Matras, Craig



Overpressure processing is a form of Hot Isostatic Pressing (HIP)


OP processing – gas pressure squeezes wire to remove bubbles

- Flow-through mixture of Ar and O₂
- Total OP pressure \leq 100 bar
- Wire or tape must be hermetically sealed
 - Ag sheath provides the seal
- Ar – presses on Ag sheath – removes bubbles
- O₂ – diffuses through Ag - sets thermodynamic condition needed to form Bi-2212
- Use an Ar/O₂ gas mixture that sets $p_{O_2} = 1$ bar in the OP system



OP processing improves J_c by two mechanisms

- **Compresses wire so volume of Bi-2212 matches filament cavity**
 - Removes bubbles
- **Prevents gas from expanding**
 - CO_2 , H_2O
 - Eliminates dedensification and creep-induced leakage





What can happen to 2212 filaments during melt processing?


- Maximum packing density of 2212 powder in filaments is 60-70%
- Focus on the 30-40 vol% of the filament that is gas-filled void space

60% dense 2212 powder in as-drawn wire





Best case with 1 bar processing: 30-40 vol% gas bubbles in filament





Real-time, *in situ* x-ray microtomography shows how bubbles form and grow during heat treatment


- **Video shows filaments in 2212 wire
during heating and cooling in 1 bar air**

Scheuerlein




Worst case with 1 bar processing: dedensification and leakage


Internal gas pressure
expands filament hole



1 bar – dirty
powder: CO₂, H₂O



- Malagoli
- Shen




Scheuerlein





Best processing: apply overpressure to squeeze Ag so filament hole matches 2212 volume \Rightarrow 100% dense

External overpressure decreases filament hole


OP decreases wire diameter



100 bar – dirty or clean powder



Scheuerlein





Demonstrated that OP processing works for Bi-2212 with small-bore OP system

- Small OP system originally designed, built, and used for Bi-2223

ASC's 2.5-cm bore research OP system




Sumitomo Electric's 4-story-tall OP system for commercial Bi-2223 tape







Overpressure (OP) densifies 2212 wires

0.8 mm diameter
closed ends 8 cm long samples





Assumption: closed ends short samples behave the same as long coil length

- Closed ends 1 atm: gas trapped <60% dense



Courtesy Dr C. Scheuerlein

- Closed ends 100 atm OP:




Courtesy Dr C. Scheuerlein

Matras



Dense filaments are the key for high J_E



Cross section
as-drawn 37x18
(0.8mm diameter)



- J_C is calculated using the as-drawn wire filament cross sectional area (60% dense filaments)
- J_C increases (actually it triples) with decreasing wire diameter as full physical connectivity occurs.

$$J_E = \frac{I_C}{\text{area OP wire}}$$

$$J_C = \frac{I_C}{\text{area filament as - drawn wire}}$$




Experiment done on short wires (8 cm long)



OPed 2212 coil at 10 bar - generated 2.6 T in 31.2 T background = 33.8 T

10 bar OP processing

- Pressure was only high enough to prevent wire from expanding
- Did not compress Ag sheath and remove bubbles
- Insulation - $\sim 15 \mu\text{m}$ thick TiO_2



Wire dia. (mm):	1.40
nGimat Insulation (mm):	0.015
Turn-turn non-tightness (mm):	0.085
layer-layer tightness (mm):	-0.065
Inner Radius (a1) (mm):	7.25
Outer Radius (a2) (mm):	18.17
Height (2b) (mm):	71.21
Radial Layers (-):	8
Turns/Layer (-):	47
Total turns (-):	376
Conductor Length (m):	30.03



Deltech built a large OP furnace for Bi-2212 coils - custom built, first of its kind

ASC's 2.5-cm bore research OP system




Deltech 100 bar OP furnace





50 bar processing is adequate for NMR demonstration coil

Experiment done on short wires (8 cm long) (37x18)



- 35 m long 10 bar coil fell on the curve





4.2 % decrease in wire diameter at 100 atm

100 bar OP significantly decreases the wire diameter.

Issue:

For magnet construction, this change in diameter poses an interesting challenge.





Matras



OP furnace and coil being developed together for high-field NMR project

High field coil + shim coils for 1 GHz (24 T) NMR demonstration magnet

Mockup of coil for NMR demonstration project



- 6.6 T
- 240 mm high
- 92 mm OD
- 44 mm ID
- 0.7 km wire
- 179 turns
- 18 layers






“Platypus”: A Bi-2212 NMR Demo-Magnet

Goals:

- **MagSci Goal: 30 T NMR magnet using HTS**
- NMR demo magnet of ~ 1 GHz (24 T) with ppm field homogeneity and stability
- Hybrid LTS/HTS coil with all conductors twisted, round and multifilament (16 T Nb-Ti/Nb₃Sn + 8 T Bi-2212)

Status:



- Novel 2212 HTS technology has been led by NHMFL
- All sub-systems demonstrated
- Platypus test planned for summer 2015
- Strong DOE-HEP and CERN support for conductor development with industrial partner OST




Bismuth Strand and Cable Collaboration BSCCo



Long-length insulation developed in-house – now SBIR partner with nGimat



Insulation coat



- TiO_2 particles suspended in organic binder
- $\sim 30 \mu\text{m}$ thick adherent coating
- Burn out before OP heat treatment





Platypus test coils 2015 (“Platypups”)


“Platylong”



“Platypup”



Coil support



- Test coils demonstrated:
 - Thermally homogeneous processing of long, thick coils
 - Reasonable correlation of coil and finite element analysis models
 - Viable terminal design
 - 4% wire densification being dealt with
 - Successful epoxy impregnation
- Some coils have been tested in 17 T background at the NHMFL
- Some coils have been dissected for further analysis of the winding pack and transport characterization of extracted coil segments
- Two additional Platypup test coils done in June 2015



Platypus test coils

Platypus test coils

- **Platylong** – full length, 3 layer

Evaluate sag from 4% wire shrinkage, furnace uniformity

- **Platypup 1** – 1/10 length, full thickness

Impregnation, leads, insulation, 17 T test

- **Platypup 2** – 2/10 length, full thickness (smaller diameter wire)

Impregnation, overbanding, confirm FEA modelling, 17 T test

- **Platypup 3** – 1/10 length, full thickness

Impregnation, variations in coil winding, 17 T test



The pluses and minuses of 2212

Pluses

- **Round, multifilament and twisted**
 - Small magnetization and small field errors
 - Highest J_E of any present HTS
 - Isotropic electromagnetic properties
- **Flexible architecture**
 - Not one-size-fits-all, like REBCO and Bi-2223

Minuses

- Must be wound in unreacted form and taken through complex HT by magnet builder under 20-100 bar pressure (1 bar O_2) at up to 890 °C
- **Must be insulated prior to heat treatment – done!**
- 4% densification under pressure needs compensation – **being addressed!**
- Wire is mechanically weak



100 bar, 900 °C Deltech
furnace with 14 cm diam. X 50
cm long hot zone



Summary

- **OP processing makes Bi-2212 round wire a viable conductor for high-field magnets – single strand or cables**
- **Round wire geometry – or wire with small aspect ratio – is preferred geometry to build magnets**
- **Bi-2212 being used in 1 GHz (24 T all SC) demonstration NMR magnet**
- **Subscale coils are being tested on path to full-scale NMR demonstration coils**